

waterproof. Stains simply wipe off.

charts too. Chinagraph pencil notations can be made and removed repeatedly.

by strengthening the spine.

Ven BOOK COVERING FILM



Books are expensive and quickly become tattered and soiled. Ven Gazzar saves you money by keeping books in new condition for years. It can actually double the life of both hardbacks and paperbacks. Because it is made from sparkling clear polypropylene it contains no environment polluting PVC, remains flexible in all climatic conditions, has minimum stretch for a smooth, wrinkle-free finish, and can be photocopied.

Ven@great is also ideal for preserving maps, wall charts and your favourite magazines, posters and prints.

Available in 15 metre rolls x 300mm, 450mm and 900mm. Special sizes cut to order from 75mm to 900mm.



555 Church Street, Richmond, Vic. 3121 25 Nicholson Street, Abbotsford, Vic. 3067, Melbourne, Australia. Phone: (03) 9428 1652. Fax Nos: (03) 9429 5506, 9429 5110, 9428 7995.






## **BOOK COVERING FILM**

HANDY APPLICATION HINTS



Unroll to the approximate length required, with the backing side up. Lay the open book over it and cut out allowing 3.5cm all around.



Separate half the backing paper by peeling it to the centre. Line up the edges and crease it in half.




Lay the centre of the book's spine along the crease then carefully rotate the books cover onto the adhesive



Trim off the corners and make cuts in towards the spine as illustrated. Retain the off-cuts for reinforcing the corners (step 6).



Starting from the centre of each edge, fold the flaps over the cover. Trim off excess at spine.



Remove the remaining backing paper and repeat steps 4 and 5 for the other cover, then seal the corners using the off-cuts saved in step 4.

## **HOW TO COVER** BOXES 3) 2) 3) Peel off the backing and place the

1) Measure the length, width and height of the box.

2) Mark these measurements onto Ven Gaver, allowing 3.5cm for the overlaps, then cut out.

bottom of the box onto the adhesive surface. Starting with the surfaces marked "C" on the illustration, carefully smooth Von @@@@co.



1) Cut evenly spaced slits through the overlap of Ven Garar as shown.

2) Fold the flaps neatly O over the edge or corner.



no creases or wrinkles. Before removing backing paper, cut to approximate size allowing 2cm all around.







1. Ensure map is clean and has 2. With the backing side up, separate half the backing paper by peeling it to the centre. Line up the edges and crease it in

3. Lay the centre of the map along the crease then carefully smooth the map onto the adhesive surface, a little at a time, working from the centre outwards.



Remove the remaining backing paper and smooth down the other half of the map in the same way; then using a sharp hobby knife, trim the film flush with map edges.



555 Church Street, Richmond, Vic. 3121 25 Nicholson Street, Abbotsford, Vic. 3067, Melbourne, Australia. Phone: (03) 9428 1652. Fax Nos: (03) 9429 5506, 9429 5110, 9428 7995.